



USER'S MANUAL

HYBRID SOLAR INVERTER 3-12KW

SRP-UN-G3-12KW



Appliances



PC



TV



Air-conditioning



Fridge



Washing machine

Contents

1. Safety Introductions	01
2. Product instructions	02-04
2.1 Product Overview	
2.2 Product Size	
2.3 Product Features	
2.4 Basic System Architecture	
3. Installation	05-23
3.1 Parts list	
3.2 Mounting instructions	
3.3 Battery connection	
3.4 Grid connection and backup load connection	
3.5 PV Connection	
3.6 CT Connection	
3.6.1 Meter Connection	
3.7 Earth Connection(mandatory)	
3.8 WIFI Connection	
3.9 Wiring System for Inverter	
3.10 Typical application diagram of diesel generator	
3.11 Single phase parallel connection diagram	
3.12 Three phase Parallel Inverter	
4. OPERATION	23
4.1 Power ON/OFF	
4.2 Operation and Display Panel	
5. LCD Display Icons	24-36
5.1 Main Screen	
5.2 Solar Power Curve	
5.3 Curve Page-Solar & Load & Grid	
5.4 System Setup Menu	
5.5 Basic Setup Menu	
5.6 Battery Setup Menu	
5.7 System Work Mode Setup Menu	
5.8 Grid Setup Menu	
5.9 Generator Port Use Setup Menu	
5.10 Advanced Function Setup Menu	
5.11 Device Info Setup Menu	
6. Mode	36-38
7. Fault information and processing	38-41
8. Limitation of Liability	41
9. Datasheet	42-43
10. Appendix I	43-45
11. Appendix II	46

Safety Introductions

About This Manual

The manual mainly describes the product information, guidelines for installation, operation and maintenance. The manual cannot include complete information about the photovoltaic (PV) system.

How to Use This Manual

Read the manual and other related documents before performing any operation on the inverter. Documents must be stored carefully and be available at all times.

Contents may be periodically updated or revised due to product development. The information in this manual is subject to change without notice.

1. Safety Introductions

Safety signs



The DC input terminals of the inverter must not be grounded.



Surface high temperature, Please do not touch the inverter case.



The AC and DC circuits must be disconnected separately, and the maintenance personnel must wait for 5 minutes before they are completely powered off before they can start working.



Prohibit disassembling inverter case, there existing shock hazard, which may cause serious injury or death, please ask qualified person to repair.

High touch current earth connection essential before connecting supply.



Please read the instructions carefully before use.



Do Not put it in the waste bin! Recycle it by licensed professional!


- This chapter contains important safety and operating instructions. Read and keep this manual for future reference.
- Before using the inverter, please read the instructions and warning signs of the battery and corresponding sections in the instruction manual.
- Do not disassemble the inverter. If you need maintenance or repair, take it to a professional service center.
- Improper reassembly may result in electric shock or fire.
- To reduce risk of electric shock, disconnect all wires before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- Caution: Only qualified personnel can install this device with battery.
- Never charge a frozen battery.
- For optimum operation of this inverter, please follow required specification to select appropriate cable size. It is very important to correctly operate this inverter.
- Be very cautious when working with metal tools on or around batteries. Dropping a tool may cause a spark or short circuit in batteries or other electrical parts, even cause an explosion.
- Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to "Installation" section of this manual for the details.
- Grounding instructions - this inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- Never cause AC output and DC input short circuited. Do not connect to the mains when DC input short circuits.

Product Introductions

2. Product Introductions

This is a multifunctional inverter, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user configurable and easy accessible button operation such as battery charging, AC/solar charging, and acceptable input voltage based on different applications.

2.1 Product Overview



1: Inverter indicators

2: LCD display

3: Function buttons

4: Power on/off button

5: PV switch

6: Box

7: PV1+

8: PV1-

9: PV2+

10: PV2-

11: Bat+

12: Bat-

13: GRID





14: LAOD

15: GEN

16: WiFi Interface

* for some hardware versions, the circuit breaker of Grid is not existed

2.2 Product Size



Product Introductions

2.3 Product Features

- Self-consumption and feed-in to the grid.
- Auto restart while AC is recovering.
- Programmable supply priority for battery or grid.
- Programmable multiple operation modes: On grid, off grid and UPS.
- Configurable battery charging current/voltage based on applications by LCD setting.
- Configurable AC/Solar/Generator Charger priority by LCD setting.
- Compatible with mains voltage or generator power.
- Overload/over temperature/short circuit protection.
- Smart battery charger design for optimized battery performance
- With limit function, prevent excess power overflow to the grid.
- Supporting WIFI monitoring and build-in 2 strings of MPPT trackers
- Smart settable three stages MPPT charging for optimized battery performance.
- Time of use function.
- Smart Load Function.


2.4 Basic System Architecture

The following illustration shows basic application of this inverter. It also includes following devices to have a complete running system.

- Generator or Utility
- PV modules

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor type appliances such as refrigerator and air conditioner.










Installation

3.Installation

3.1 Parts List

Check the equipment before installation. Please make sure nothing is damaged in the package. You should have received the items in the following package:



Installation


3.2 Mounting instructions

Installation Precaution

This Hybrid inverter is designed for outdoor use(IP65), Please make sure the installation site meets below conditions:


- Not in direct sunlight
- Not in areas where highly flammable materials are stored.
- Not in potential explosive areas.
- Not in the cool air directly.
- Not near the television Antenna or antenna cable.
- Not higher than altitude of about 2000 meters above sea level.
- Not in environment of precipitation or humidity(>95%)

Please AVOID direct sunlight, rain exposure, snow laying up during installation and operation. Before connecting all wires, please take off the metal cover by removing screws as shown below:



Considering the following points before selecting where to install:

- Please select a vertical wall with load-bearing capacity for installation, suitable for installation on concrete or other non-flammable surfaces, installation is shown below.
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- The ambient temperature is recommended to be between -40~60°C to ensure optimal operation.
- Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and have enough space for removing wires.




For proper air circulation to dissipate heat, allow a clearance of approx. 50cm to the side and approx. 50cm above and below the unit. And 100cm to the front.


Considering the following points before selecting where to install:

Remember that this inverter is heavy! Please be careful when lifting out from the package. Choose the recommend drill head(as shown in below pic) to drill 4 holes on the wall, 72-80mm deep.

1. Use a proper hammer to fit the expansion bolt into the holes.
2. Carry the inverter and holding it, make sure the hanger aim at the expansion bolt,fix the inverter on the wall.
3. Fasten the screw head of the expansion bolt to finish the mounting.



Inverter hanging plate installation



3.3 Battery connection

For safe operation and compliance, a separate DC over-current protector or disconnect device is required between the battery and the inverter. In some applications, switching devices may not be required but over-current protectors are still required. Refer to the typical amperage in the table below for the required fuse or circuit breaker size.

Model	Wire Size	Cable(mm ²)	Torque value(max)
3/3.6kW	4AWG	25	24.5Nm
4.2/5/6kW	2AWG	35	24.5Nm
8kW	1AWG	50	24.5Nm
10/12kW	0AWG	55	24.5Nm

Chart 3-2 Cable size

Installation




All wiring must be performed by a professional person.




Connecting the battery with a suitable cable is important for safe and efficient operation of the system. To reduce the risk of injury, refer to Chart 3-2 for recommended cables.

Please follow below steps to implement battery connection:

1. Please choose a suitable battery cable with correct connector which can well fit into the battery terminals.
2. Use a suitable screwdriver to unscrew the bolts and fit the battery connectors in, then fasten the bolt by the screwdriver, make sure the bolts are tightened with torque of 5.2 N.M in clockwise direction.
3. Make sure polarity at both the battery and inverter is correctly connected.
4. In case of children touch or insects go into the inverter, Please make sure the inverter connector is fasten to waterproof position by twist it clockwise.




For 3-6kW model,
battery connector screw size: M6



DC Battery Input

For 8-12kW model,
battery connector screw size: M10



DC Battery Input




Installation must be performed with care.





Before making the final DC connection or closing DC breaker/disconnect, be sure positive(+) must be connect to positive(+) and negative(-) must be connected to negative(-). Reverse polarity connection on battery will damage the inverter.

3.3.2 Function port definition



Inverter

DIP Switch




When the "GEN signal" is active, the open contact (GV/GS) will switch on (no voltage output). If the "Signal ISLAND MODE" is ticked, the GS port will be the dry contact signal for startup the diesel generator. If "Signal ISLAND MODE" is not ticked, the GV port will be the dry contact signal for startup the diesel generator.

ATS: 230V output port when inverter is on.


DIP switch: Parallel communication resistor. If the number of inverters in the parallel system is less than or equal to 6, all inverter's DIP switch (1&2) need be ON position.

If the number of inverters in parallel system exceeds 6, the main 6pcs inverter's DIP switch needs to be ON position. And the other inverter DIP switch (1&2) needs to be OFF position.



(diesel generator startup signal)

3.3.3 Temperature sensor connection for lead-acid battery



3.4 Grid connection and backup load connection

- Before connecting to the grid, a separate AC breaker must be installed between the inverter and the grid, and also between the backup load and the inverter. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current. For the 3/3.6/4.2/5/6/8/10/12KW model, the recommended AC breaker for backup load 3/3.6KW is 32A, 4.2/5/6KW is 40A, 8KW is 63A, 10/12KW is 100A. For the 3/3.6/4.2/5/6/8/10/12KW model, the recommended AC breaker for grid 3/3.6KW is 32A, 4.2/5/6KW is 40A, 8KW is 63A, 10/12KW is 100A.
- There are three terminal blocks with "Grid" "Load" and "GEN" markings. Please do not misconnect input and output connectors.







All wiring must be performed by a qualified personnel. It is very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable as below.

Model	Wire Size	Cable(mm ²)	Torque value(max)
3/3.6kW	10AWG	5	1.2Nm
4.2/5/6kW	8AWG	8	1.2Nm
8kW	6AWG	13	1.2Nm
10/12kW	4AWG	21.1	1.2Nm

Chart 3-3 Recommended Size for AC wires

Please follow below steps to implement AC input/output connection:

1. Before making Grid, load and Gen port connection, be sure to turn off AC breaker or disconnect first.
2. Remove insulation sleeve 10mm length, unscrew the bolts, insert the wires according to polarities indicated on the terminal block and tighten the terminal screws. Make sure the connection is complete.





Be sure that AC power source is disconnected before attempting to wire it to the unit.

3. Then, insert AC output wires according to polarities indicated on the terminal block and tighten terminal. Be sure to connect corresponding N wires and PE wires to related terminals as well.
4. Make sure the wires are securely connected.
5. Appliances such as air conditioner are required at least 2-3 minutes to restart because it is required to have enough time to balance refrigerant gas inside of circuit. If a power shortage occurs and recovers in short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it is equipped with time-delay function before installation. Otherwise, this inverter will trigger overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

3.5 PV Connection

Before connecting to PV modules, please install a separately DC circuit breaker between inverter and PV modules. It is very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

Model	Wire Size	Cable(mm ²)
3/3.6/4.2/5/6/8/10/12kW	12AWG	4

Chart 3-4 Cable size



To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.



It is requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

Installation

3.5.1 PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

- 1) Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
- 2) Open circuit Voltage (Voc) of PV modules should be higher than min. start voltage.
- 3) The PV modules used to connected to this inverter shall be Class A rating certified according to IEC 61730.


Inverter Model	3kW	3.6kW	4.2kW	5kW	6kW	8kW	10kW	12kW
PV Input Voltage	370V (125V~500V)							
PV Array MPPT Voltage Range	150V-425V							
No. of MPPT Trackers	2	2	2	2	2	2	3	3
No. of Strings per MPPT Tracker	1+1	1+1	1+1	1+1	1+1	1+1	1+1+1	1+1+1

Chart 3-5


3.5.2 PV Module Wire Connection:

Please follow below steps to implement PV module connection:

1. Remove insulation sleeve 10 mm for positive and negative conductors.
2. Suggest to put bootlace ferrules on the end of positive and negative wires with a proper crimping tool.
3. Check correct polarity of wire connection from PV modules and PV input connectors. Then, connect positive pole (+) of connection wire to positive pole (+) of PV input connector. Connect negative pole (-) of connection wire to negative pole (-) of PV input connector. Close the switch and make sure the wires are tightly fixed.




3.6 CT Connection




Note: when the reading of the load power on the LCD is not correct, please reverse the CT arrow.

The primary side of the CT needs to be clamped on the Grid live line.

3.6.1 Meter Connection



Installation




Note:

In final installation, breaker certified according to IEC 60947-1 and IEC 60947-2 shall be installed with the equipment.

3.7 Earth Connection(mandatory)

Ground cable shall be connected to ground plate on grid side this prevents electric shock. if the original protective conductor fails.





Model	Wire Size	Cable(mm ²)	Torque value(max)
3/3.6kW	10AWG	5	1.2Nm
4.2/5/6kW	8AWG	8	1.2Nm
8kW	6AWG	13	1.2Nm
10/12kW	5AWG	16	1.2Nm

3.8 WIFI Connection

For the configuration of Wi-Fi Plug, please refer to illustrations of the Wi-Fi Plug. The Wi-Fi Plug is not a standard configuration, it's optional.


3.9 Wiring System for Inverter



3.10 Typical application diagram of diesel generator


(Region:EU)

CAN L N wire PE wire



Installation

3.11 Single phase parallel connection diagram



Master Inverter

Advanced Function 2

Parallel A Phase
 Master B Phase
 Slave C Phase

Ex. Meter For CT Meter Select: No Meter
 A Phase
 B Phase
 C Phase ATIS OFF

Slave Inverter

Advanced Function 2

Parallel A Phase
 Master B Phase
 Slave C Phase

Ex. Meter For CT Meter Select: No Meter
 A Phase
 B Phase
 C Phase ATIS OFF


Slave Inverter

Advanced Function 2

Parallel A Phase
 Master B Phase
 Slave C Phase

Ex. Meter For CT Meter Select: No Meter
 A Phase
 B Phase
 C Phase ATIS OFF

Installation



Advanced Function 2

Parallel Modbus SN A Phase

Master SI B Phase

Slave C Phase

Ex_Meter For CT Meter Select No Meter

A Phase B Phase C Phase

AT5 OFF

Advanced Function 2

Parallel Modbus SN A Phase

Master SI B Phase

Slave C Phase

Ex_Meter For CT Meter Select No Meter

A Phase B Phase C Phase

AT5 OFF

Advanced Function 2

Parallel Modbus SN A Phase

Master SI B Phase

Slave C Phase



Ex_Meter For CT Meter Select No Meter

A Phase B Phase C Phase

AT5 OFF

3.12 Three phase Parallel Inverter

— CAN — L — N wire — PE wire



4. OPERATION

4.1 Power ON/OFF

Once the unit has been properly installed and the batteries are connected well, simply press On/Off button(located on the left side of the case) to turn on the unit.When system without battery connected, but connect with either PV or grid, and ON/OFF button is switched off, LCD will still light up(Display will show OFF), In this condition, when switch on ON/OFF button and select NO battery, system can still working.

4.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes four indicators, four function keys and a LCD display, indicating the operating status and input/output power information.

LED Indicator		Messages
DC	Green led solid light	PV Connection normal
AC	Green led solid light	Grid Connection normal
Normal	Green led solid light	Inverter operating normal
Alarm	Red led solid light	Malfunction or warning

Chart 4-1 LED indicators


LED Indicator	Description
Esc	To exit setting mode
Up	To go to previous selection
Down	To go to next selection
Enter	To confirm the selection

Chart 4-2 Function Buttons

5. LCD Display Icons

5.1 Main Screen

The LCD is touchscreen, below screen shows the overall information of the inverter.



1.The icon in the center of the home screen indicates that the system is Normal operation. If it turns into "comm./F01-F64",it means the inverter has communication errors or other errors,the error message will display under this icon(F01-F64 errors, detail error info can be viewed in the System Alarms menu).


2.At the top of the screen is the time.

3.System Setup Icon, Press this set button,you can enter into the system setup screen which including Basic Setup, Battery Setup, Grid Setup, System Work Mode, Generator port use, Advanced function and Li-Batt info.

4.The main screen showing the info including Solar, Grid, Load and Battery. Its also displaying the energy flow direction by arrow. When the power is approximate to high level, the color on the panels will changing from green to red so system info showing vividly on the main screen.

- PV power and Load power always keep positive.
- Grid power negative means sell to grid, positive means get from grid.
- Battery power negative means charge, positive means discharge.

5.1.1 LCD operation flow chart



5.2 Solar Power Curve

Solar

Power: 0W	①	Today=0.3 KWH	②
		Total =5.0 KWH	
PV1-V: 0V	PV2-V: 0V	PV3-V: 0V	③
PV1-I: 0A	PV2-I: 0.1A	PV3-I: 0.0A	
P1: 0W	P2: 0W	P3: 0W	

Energy

This is Solar Panel detail page.

- ① Solar Panel Generation.
- ② Solar Panel energy for Day and Total.
- ③ Voltage, Current, Power for each MPPT.

Press the "Energy" button will enter into the power curve page.

*** Note:** this part info is not available for some LCD FW.

Inverter

Power: 128W	Fre: 50.00Hz
L1_V: 230V	L2_V: NA
I1: 0.6A	I2: NA
INV_P1: 0W	INV_P2: NA

This is Inverter detail page.

Inverter Generation.

Voltage, Current, Power for each Phase.

*** Note:** this part info is not available for some LCD FW.

Load

Power: 0W	①	Today=0.0KWH	③
		Total=2.40KWH	
L1:0V	L2:0V	②	
P1:0V	P2:0V		

Energy

This is Back-up Load detail page.

- ① Back-up Power.
- ② Voltage, Power for each Phase.
- ③ Back-up consumption for Day and Total.

Press the "Energy" button will enter into the power curve page.

*** Note:** this part info is not available for some LCD FW.

Grid

Stand-by Power: 0W	①	BUY	③
Fre: 0.0Hz		Today=2.2KWH	Total =13.60 KWH
L1:0V	L2:0V	SELL	②
CT1:0W	CT2:0W	Today=0.0KWH	
LD1:0W	LD2:0W	Total =9.60 KWH	

Energy

This is Back-up Load detail page.

- ① Status, Power, Frequency.
- ② L: Voltage for each Phase

CT: Power detected by the external current sensors

LD: Power detected using internal sensors on AC grid in/out breaker

- ③ **BUY:** Energy from Grid to Inverter,
- SELL:** Energy from Inverter to grid.


Press the "Energy" button will enter into the power curve page.

*** Note:** this part info is not available for some LCD FW.

LCD Display Icons

Batt


Stand-by
 SOC: 36%
 U: 50.50V
 I: -30.02A
 Power: -1517W
 Temp: 35.0°C



Li-BMS

Mean Voltage : 50.50V
 Total Current : 55.00A
 Mean Temp : 25.5°C
 Total SOC : 50%
 Dump Energy : 80Ah





Charging Voltage : 53.2V
 Discharging Voltage : 47.0V
 Charging current : 30A
 Discharging current : 50A



This is Battery detail page.
 if you use Lithium Battery, you can enter BMS page.

* **Note:** this part info is not available for some LCD FW.

5.3 Curve Page-Solar & Load & Grid




Solar power curve for daily, monthly, yearly and total can be roughly checked on the LCD, for more accuracy power generation, pls check on the monitoring system. Click the up and down arrow to check power curve of different period.

* **Note:** this part info is not available for some LCD FW.


LCD Display Icons

5.4 System Setup Menu



This is System Setup page.

5.5 Basic Setup Menu



Factory Reset: Reset all parameters of the inverter.

Before performing a successful factory reset and locking the systems, to keep all changes you need to type in a password to enable the setting.

The password for factory settings is 1918.

*** Note:** this part info is not available for some LCD FW.



Factory Reset Password: 1918

*** Note:** this part info is not available for some LCD FW.

5.6 Battery Setup Menu

Battery Setting 1

Batt Mode

- Lithium
- Use Batt V
- Use Batt %
- No Batt

Batt Capacity

Max A Charge

Max A Discharge

Activate Battery



Battery capacity: it tells US hybrid inverter to know your battery bank size.

Use Batt V: Use Battery Voltage for all the settings (V).

Use Batt %: Use Battery SOC for all the settings (%).

Max. A charge/discharge: Max battery charge/discharge current(0-120A for 5kW model, 0-135A for 6kW model, 0-190A for 8kW model).

For AGM and Flooded, we recommend Ah battery size x 20%= Charge/Discharge amps.

. For Lithium, we recommend Ah battery size x 50% = Charge/Discharge amps.

. For Gel, follow manufacturer' s instructions.

No Batt: tick this item if no battery is connected to the system.

Active battery: This feature will help recover a battery that is over discharged by slowly charging from the solar array or grid.

* **Note:** this part info is not available for some LCD FW.

Battery Setting 2

Start

A

Gen Charge

Gen Signal

Gen Force

Grid Charge

Grid Signal

Gen Force



This is Battery Setup page. ①③

Start =30%: Percent S.O.C at 30% system will AutoStart a connected generator to charge the battery bank.

A= 40A: Charge rate of 40A from the attached generator in Amps.

Gen Charge: uses the gen input of the system to charge battery bank from an attached generator.

Gen Signal: Normally open relay that closes when the Gen Start signal state is active.

Gen Force: When the generator is connected, it is forced to start the generator without meeting other conditions.

Low Noise Mode: In this mode, inverter will work in "low noise mode".

This is Grid Charge, you need select. ②


Start =30%: No use, Just for customization.

A= 40A: It indicates the Current that the Grid charges the Battery.

Grid Charge: It indicates that the grid charges the battery.

Grid Signal: Disable.

* **Note:** this part info is not available for some LCD FW.



This page tells the PV and diesel generator power the load and battery.

LCD Display Icons

Generator

Power: 1392W Today=0.0 KWH
 Total=2.20 KWH

L1: 228V

Freq:50.0Hz

This page tells generator output voltage, frequency, power. And, how much energy is used from generator.

* **Note:** this part info is not available for some LCD FW.

Battery Setting 3

Lithium Mode

Shutdown

Low Batt

Restart



Lithium Mode: This is BMS protocol. Please reference the document (Approved Battery).

Shutdown 10%: It indicates the inverter will shutdown if the SOC below this value.

Low Batt 20%: It indicates the inverter will alarm if the SOC below this value.

Restart 40%: Battery voltage at 40% AC output will resume.

* **Note:** this part info is not available for some LCD FW.

Battery Setting 3

Float V ^①

Absorption V

Equalization V

Equalization Days

Equalization Hours

Shutdown ^③

Low Batt

Restart

TEMPCO(mV/C/Cell) ^②

Batt Resistance



There are 3 stages of charging the Battery .

This is for professional installers, you can keep it if you do not know. ^①

Shutdown 20%: The inverter will shutdown if the SOC below this value. ^②

Low Batt 35%: The inverter will alarm if the SOC below this value. ^③

Restart 50%: Battery SOC at 50% AC output will resume.

Recommended battery settings

Battery Type	Absorption Stage	Float Stage	Torque value (every 30 days 3hr)
AGM (or PCC)	14.2V (57.6V)	13.4V (53.6V)	14.2V (57.6V)
Gel	14.1V (56.4V)	13.5V (54.0V)	
Wet	14.7V (59.0V)	13.7V (55.0V)	14.7V (59.0V)
Lithium	Follow its BMS voltage parameters		

5.7 System Work Mode

System Work Mode 1

Selling First 5000W Max Solar Power

Zero Export To Load Solar Sell

Zero Export To CT Solar Sell

Max Sell Power 8000w Energy pattern

Zero-export Power 20w BattFirst v

Grid Peak Shaving 5000W Power

Work Mode


Selling First: This Mode allows hybrid inverter to sell back any excess power produced by the solar panels to the grid. If time of use is active, the battery energy also can be sold into grid.

The PV energy will be used to power the load and charge the battery and then excess energy will flow to grid.


Power source priority for the load is as follows:

- 1.Solar Panels.
- 2.Grid.
- 3.Batteries (until programable % discharge is reached).

Zero Export To Load: Hybrid inverter will only provide power to the backup load connected. The hybrid inverter will neither provide power to the home load nor sell power to grid. The built-in CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load and charge the battery.



Zero Export To CT: Hybrid inverter will not only provide power to the backup load connected but also give power to the home load connected. If PV power and battery power is insufficient, it will take grid energy as supplement. The hybrid inverter will not sell power to grid. In this mode, a CT is needed. The installation method of the CT please refer to chapter 3.6 CT Connection. The external CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load, charge battery and home load.



LCD Display Icons

Solar Sell: "Solar sell" is for Zero export to load or Zero export to CT: when this item is active, the surplus energy can be sold back to grid. When it is active, PV Power source priority usage is as follows: load consumption and charge battery and feed into grid.

Max. sell power: Allowed the maximum output power to flow to grid.

Zero-export Power: for zero-export mode, it tells the grid output power. Recommend to set it as 20-100W to ensure the hybrid inverter won't feed power to grid.

Energy Pattern: PV Power source priority.

Batt First: PV power is firstly used to charge the battery and then used to power the load. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Load First: PV power is firstly used to power the load and then used to charge the battery. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Max Solar Power: allowed the maximum DC input power.

Grid Peak-shaving: when it is active, grid output power will be limited within the set value. If the load power exceeds the allowed value, it will take PV energy and battery as supplement. If still can't meet the load requirement, grid power will increase to meet the load needs.

System Work Mode 2

Mon Tue Wed
 Thu Fri Sat
 Sun Time of use



Time of use: it is used to program when to use grid or generator to charge the battery, and when to discharge the battery to power the load. Only tick "Time Of Use" then the follow items (Grid, charge, time, power etc.) will take effect.

Note: when in selling first mode and click time of use, the battery power can be sold into grid.

It allows users to choose which day to execute the setting of "Time of Use".

For example, the inverter will execute the time of use page on Mon/Tue/Wed/Thu/Fri/Sat only.

* **Note:** this part info is not available for some LCD FW.

System Work Mode 3

Grid Charge	Gen	Time	Power	Batt
<input type="checkbox"/>	<input type="checkbox"/>	01:00 - 5:00	5000	49.0V
<input type="checkbox"/>	<input type="checkbox"/>	05:00 - 9:00	5000	50.2V
<input checked="" type="checkbox"/>	<input type="checkbox"/>	09:00 - 13:00	5000	50.9V
<input checked="" type="checkbox"/>	<input type="checkbox"/>	13:00 - 17:00	5000	51.4V
<input checked="" type="checkbox"/>	<input type="checkbox"/>	17:00 - 21:00	5000	47.1V
<input checked="" type="checkbox"/>	<input type="checkbox"/>	21:00 - 01:00	5000	49.0V



Grid charge: utilize grid to charge the battery in a time period.

Gen charge: utilize diesel generator to charge the battery in a time period.

Time: real time, range of 01:00-24:00.

Power: Max. discharge power of battery allowed.action is to happen.

Batt(V or SOC %): battery SOC % or voltage at when the action is to happen.

For example:

During 01:00-05:00, when battery SOC is lower than 80%, it will use grid to charge the battery until battery SOC reaches 80%.

During 05:00-08:00 and 08:00-10:00, when battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%.

During 10:00-15:00, when battery SOC is higher than 80%, hybrid inverter will discharge the battery until the SOC reaches 80%.

During 15:00-18:00, when battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%.

During 18:00-01:00, when battery SOC is higher than 35%, hybrid inverter will discharge the battery until the SOC reaches 35%.

* **Note:** this part info is not available for some LCD FW.

System Work Mode 3

Grid Charge	Gen	Time	Power	Batt
<input checked="" type="checkbox"/>	<input type="checkbox"/>	01:00 - 5:00	5000	80%
<input type="checkbox"/>	<input type="checkbox"/>	05:00 - 8:00	5000	40%
<input type="checkbox"/>	<input type="checkbox"/>	08:00 - 10:00	5000	40%
<input type="checkbox"/>	<input type="checkbox"/>	10:00 - 15:00	5000	80%
<input type="checkbox"/>	<input type="checkbox"/>	15:00 - 18:00	5000	40%
<input type="checkbox"/>	<input type="checkbox"/>	18:00 - 01:00	5000	35%



5.8 Grid Setup Menu

Grid Setting 1/Grid code selection

Grid Mode	General Standard	↓
Grid Frequency	50HZ	×
INV Output Voltage	230V	↓
Grid Type	Single Phase	×
		✓

Grid Mode: General Standard, UL1741 & IEEE1547, CPUC RULE21, SRD-UL-1741, CEI 0-21, EN50549_CZ, Australia_A, Australia_B, Australia_C, NewZealand, VDE4105, OVE_Directive_R25, EN50549_CZ_PPDS_L16A, NRS097, G98/G99, G98/G99_NI, ESB Networks(Ireland). Please follow the local grid code and then choose the corresponding grid standard.

Grid Warning

Grid Mode: Grid Standard
 Grid Fre: 50HZ
 Grid Level: single phase
 Inv Output: 220V

Please make sure that settings are correct before clicking OK, otherwise the inverter will be damaged!!!

×

✓

This is Grid Warning page.

Grid Setting 2/Connect

Normal connect	Normal Ramp rate	60s	
Low frequency	48.00Hz	High frequency	51.50Hz
Low voltage	185.0V	High voltage	265.0V
Reconnect after trip	Reconnect Ramp rate	60s	
Low frequency	48.20Hz	High frequency	51.30Hz
Low voltage	187.0V	High voltage	263.0V
Reconnection Time	60s	PF	1.000

↑

↓

×

✓

Normal connect: The allowed grid voltage/frequency range when the inverter first time connect to the grid.
Normal Ramp rate: It is the startup power ramp.
Reconnect after trip: The allowed grid voltage/frequency range for the inverter connects the grid after the inverter trip from the grid.
Reconnect Ramp rate: It is the reconnection power ramp.
Reconnection time: The waiting time period for the inverter connects the grid again.
PF: Power factor which is used to adjust inverter reactive power.

Grid Setting 3/IP Protection

Over voltage U>(10 min. running mean)	260.0V		
HV3	265.0V	HF3	51.50Hz
① HV2	265.0V	② HF2	51.50Hz
	0.10s		0.10s
HV1	265.0V	HF1	51.50Hz
	0.10s		0.10s
LV1	185.0V	LF1	48.00Hz
	0.10s		0.10s
LV2	185.0V	LF2	48.00Hz
	0.10s		0.10s
LV3	185.0V	LF3	48.00Hz

↑

×

✓

HV1: Level 1 overvoltage protection point;
 ① HV2: Level 2 overvoltage protection point; ② 0.10s—Trip time.
 HV3: Level 3 overvoltage protection point.
 LV1: Level 1 undervoltage protection point;
 LV2: Level 2 undervoltage protection point;
 LV3: Level 3 undervoltage protection point.
 HF1: Level 1 over frequency protection point;
 HF2: Level 2 over frequency protection point;
 HF3: Level 3 over frequency protection point.
 LF1: Level 1 under frequency protection point;
 LF2: Level 2 under frequency protection point;
 LF3: Level 3 under frequency protection point.

5.9 Generator Port use Setup Menu

GEN PORT USE

Mode

Generator Input
Rated Power

SmartLoad Output
Power

Micro Inv Input
ON(V) OFF(V)

AC Couple on grid side
 AC Couple on load side
GEN connect to Grid input On Grid always on
AC Couple Fre High

X
✓

Generator input rated power: allowed Max. power from diesel generator.

GEN connect to grid input: connect the diesel generator to the grid input port.

Smart Load Output: This mode utilizes the Gen input connection as an output which only receives power when the battery SOC and PV power is above a user programmable threshold.

e.g. Power=500W, ON: 100%, OFF=95%: When the PV power exceeds 500W, and battery bank SOC reaches 100%, Smart Load Port will switch on automatically and power the load connected. When the battery bank SOC < 95% or PV power < 500w, the Smart Load Port will switch off automatically.

Smart Load OFF Batt

- Battery SOC at which the Smart load will switch off.

Smart Load ON Batt

- Battery SOC at which the Smart load will switch on. Also, the PV input power should exceed the setting value (Power) simultaneously and then the Smart load will switch on.

On Grid always on: When click "on Grid always on" the smart load will switch on when the grid is present.

Micro Inv Input: To use the Generator input port as a micro-inverter on grid inverter input (AC coupled), this feature will also work with "Grid-Tied" inverters.

* **Micro Inv Input OFF:** when the battery SOC exceeds setting value, Microinverter or grid-tied inverter will shut down.

* **Micro Inv Input ON:** when the battery SOC is lower than setting value, Microinverter or grid-tied inverter will start to work.

AC Couple Fre High: If choosing "Micro Inv input", as the battery SOC reaches gradually setting value (OFF), During the process, the microinverter output power will decrease linear. When the battery SOC equals to the setting value (OFF), the system frequency will become the setting value (AC couple Fre high) and the Microinverter will stop working.

Stop exporting power produced by the microinverter to the grid.

* **Note:** Micro Inv Input OFF and On is valid for some certain FW version only.

* **AC couple on load side:** connecting the output of on-grid inverter at the load port of the hybrid inverter. In this situation, the hybrid inverter will not able to show the load power correctly.


* **AC couple on grid side:** this function is reserved.

* **Note:** Some firmware versions don't have this function.

5.10 Advanced Function Setup Menu

Advanced Function 1

<input type="checkbox"/> Solar Arc Fault ON	Backup Delay	
<input type="checkbox"/> Clear Arc_Fault	<input type="text" value="0ms"/>	
<input type="checkbox"/> System selfcheck	<input type="checkbox"/> Gen peak-shaving	⬇
<input type="checkbox"/> DRM	CT Ratio	<input type="text" value="0:1"/> ⬇
<input type="checkbox"/> Signal Island Mode		⊗
<input type="checkbox"/> BMS Err_Stop	<input type="checkbox"/> CEI 0-21 Report	⬆



Solar Arc Fault ON: This is only for US.

System selfcheck: Disable. this is only for factory.

Gen Peak-shaving: Enable When the power of the generator exceeds the rated value of it, the inverter will provide the redundant part to ensure that the generator will not overload.

DRM: For AS4777 standard

Backup Delay: (0-300)S adjustable

BMS Err_Stop: When it is active, if the battery BMS failed to communicate with inverter, the inverter will stop working and report fault.

Signal ISLAND MODE: when "signal island mode" is checked and the inverter connects the grid, the ATS port voltage will be 0. When "signal island mode" is checked and the inverter disconnected from the grid, the ATS port voltage will output 230vac voltage. With this feature and outside NO type relay, it can realize N and PE disconnection or bond.

More details, please refer to left side picture.

* **Note:** this part info is not available for some LCD FW.



Advanced Function 2

<input type="checkbox"/> Parallel	Modbus SN	<input checked="" type="radio"/> A Phase
<input type="radio"/> Master	<input type="text" value="00"/>	<input type="radio"/> B Phase
<input checked="" type="radio"/> Slave		<input type="radio"/> C Phase
		⬆
<input type="checkbox"/> Ex_Meter For CT	Meter Select	⊗
<input type="checkbox"/> A Phase	<input type="text" value="No Meter"/>	⬆
<input type="checkbox"/> B Phase		⬆
<input type="checkbox"/> C Phase	<input type="checkbox"/> ATS <input type="text" value="OFF"/>	⬆

Ex_Meter For CT: when in Three phase system with CHNT Three phase energy meter (DTSU666), click corresponding phase where hybrid inverter is connected. e.g. when the hybrid inverter output connects to A phase, please click A Phase.

Meter Select: select the corresponding meter type according to the meter installed in the system.

* **Note:** this part info is not available for some LCD FW.




5.11 Device Info Setup Menu

Device Info.

SRP-UN-G3-12KW Inverter ID: 1601012001
HMI: Ver 001-12 2019-03-11-10:00_C

Alarms Code Occurred 01/01
F64 Heatsink_HighTemp_Fault 03/20/2019 15:56:31




This page show Inverter ID, Inverter version and alarm codes.

HMI: LCD version


* **Note:** this part info is not available for some LCD FW.

6. Mode


Mode I: Basic






Mode II: With Generator



Mode III: With Smart-Load



Mode IV: AC Couple





The 1st priority power of the system is always the PV power, then 2nd and 3rd priority power will be the battery bank or grid according to the settings. The last power backup will be the Generator if it is available.

7. Fault information and processing

The energy storage inverter is designed according to the grid-connected operation standard and meets the safety requirements and electromagnetic compatibility requirements. Before leaving the factory, the inverter undergoes several rigorous tests to ensure that the inverter can operate reliably.



If any of the fault messages listed in Table 7-1 appear on your inverter and the fault has not been removed after restarting, please contact your local dealer or service center. You need to have the following information ready.

1. Inverter serial number;
2. Distributor or service center of the inverter ;
3. On-grid power generation date;
4. The problem description (including the fault code and indicator status displayed on the LCD) is as detailed as possible.
5. Your contact information. In order to give you a clearer understanding of the inverter's fault information, we will list all possible fault codes and their descriptions when the inverter is not working properly.

Fault information and processing

Error code	Description	Solutions
F08	GFDI _Relay_Failure	<ol style="list-style-type: none"> 1. When inverter is in Split phase(120/240Vac) or three-phase system (120/208Vac) system, the backup load port N line needs to connect ground; 2. If the fault still exists, please contact us for help.
F13	Working mode change	<ol style="list-style-type: none"> 1. When the grid type and frequency changed it will report F13; 2. When the battery mode was changed to "No battery" mode, it will report F13; 3. For some old FW version, it will report F13 when the system work mode changed; 4. Generally, it will disappear automatically when shows F13; 5. If still same, and turn off the DC switch and AC switch and wait for one minute and then turn on the DC/AC switch; 6. Seek help from us, if can not go back to normal state.
F18	AC over current fault of hardware	<p>AC side over current fault</p> <ol style="list-style-type: none"> 1. Please check whether the backup load power and common load power are within the range; 2. Restart and check whether it is in normal; 3. Seek help from us, if can not go back to normal state.
F20	DC over current fault of the hardware	<p>DC side over current fault</p> <ol style="list-style-type: none"> 1. Check PV module connect and battery connect; 2. When in the off-grid mode, the inverter startup with big power load, it may report F20. Please reduce the load power connected; 3. Turn off the DC switch and AC switch and then wait one minute, then turn on the DC/AC switch again; 4. Seek help from us, if can not go back to normal state.
F22	Tz_EmergStop_Fault	Please contact your installer for help.
F23	AC leakage current is transient over current	<p>Leakage current fault</p> <ol style="list-style-type: none"> 1. Check PV side cable ground connection. 2. Restart the system 2~3 times. 3. If the fault still exists, please contact us for help.
F24	DC insulation impedance failure	<p>PV isolation resistance is too low</p> <ol style="list-style-type: none"> 1. Check the connection of PV panels and inverter is firmly and correctly; 2. Check whether the PE cable of inverter is connected to ground; 3. Seek help from us, if can not go back to normal state.
F26	The DC busbar is unbalanced	<ol style="list-style-type: none"> 1. Please wait for a while and check whether it is normal; 2. When the hybrid in split phase mode, and the load of L1 and load of L2 is big different, it will report the F26. 3. Restart the system 2~3 times. 4. Seek help from us, if can not go back to normal state.
F29	Parallel CANBus fault	<ol style="list-style-type: none"> 1. When in parallel mode, check the parallel communication cable connection and hybrid inverter communication address setting; 2. During the parallel system startup period, inverters will report F29. when all inverters are in ON status, it will disappear automatically; <p>If the fault still exists, please contact us for help.</p>

Fault information and processing

Error code	Description	Solutions
F34	AC Overcurrent fault	<ol style="list-style-type: none"> 1. Check the backup load connected, make sure it is in allowed power range; 2. If the fault still exists, please contact us for help.
F35	No AC grid	<ol style="list-style-type: none"> 1. No Utility 2. Please confirm grid is lost or not; 3. Check the grid connection is good or not; 4. Check the switch between inverter and grid is on or not; 5. Seek help from us, if can not go back to normal state.
F41	Parallel system stop	<ol style="list-style-type: none"> 1. Check the hybrid inverter working status. If there's 1 pcs hybrid inverter is in OFF status, the other hybrid inverters may report F41 fault in parallel system. 2. If the fault still exists, please contact us for help.
F42	AC line low voltage	<p>Grid voltage fault</p> <ol style="list-style-type: none"> 1. Check the AC voltage is in the range of standard voltage in specification; 2. Check whether grid AC cables are firmly and correctly connected; 3. Seek help from us, if can not go back to normal state.
F47	AC over frequency	<p>Grid frequency out of range</p> <ol style="list-style-type: none"> 1. Check the frequency is in the range of specification or not; 2. Check whether AC cables are firmly and correctly connected; 3. Seek help from us, if can not go back to normal state.
F48	AC lower frequency	<p>Grid frequency out of range</p> <ol style="list-style-type: none"> 1. Check the frequency is in the range of specification or not; 2. Check whether AC cables are firmly and correctly connected; 3. Seek help from us, if can not go back to normal state.
F56	DC busbar voltage is too low	<p>Battery voltage low</p> <ol style="list-style-type: none"> 1. Check whether battery voltage is too low; 2. If the battery voltage is too low, using PV or grid to charge the battery; 3. Seek help from us, if can not go back to normal state.
F58	BMS communication fault	<ol style="list-style-type: none"> 1. it tells the communication between hybrid inverter and battery BMS disconnected when "BMS_Err-Stop" is active; 2. if don't want to see this happen, you can disable "BMS_Err-Stop" item on the LCD; 3. If the fault still exists, please contact us for help.
F63	ARC fault	<ol style="list-style-type: none"> 1. ARC fault detection is only for US market; 2. Check PV module cable connection and clear the fault; 3. Seek help from us, if can not go back to normal state.
F64	Heat sink high temperature failure	<p>Heat sink temperature is too high</p> <ol style="list-style-type: none"> 1. Check whether the work environment temperature is too high; 2. Turn off the inverter for 10mins and restart; 3. Seek help from us, if can not go back to normal state.

Limitation of Liability

Under the guidance of our company, customers return our products so that our company can provide service of maintenance or replacement of products of the same value. Customers need to pay the necessary freight and other related costs. Any replacement or repair of the product will cover the remaining warranty period of the product. If any part of the product or product is replaced by the company itself during the warranty period, all rights and interests of the replacement product or component belong to the company.

Factory warranty does not include damage due to the following reasons:

- Damage during transportation of equipment;
- Damage caused by incorrect installation or commissioning;
- Damage caused by failure to comply with operation instructions, installation instructions or maintenance instructions;
- Damage caused by attempts to modify, alter or repair products;
- Damage caused by incorrect use or operation;
- Damage caused by insufficient ventilation of equipment;
- Damage caused by failure to comply with applicable safety standards or regulations;
- Damage caused by natural disasters or force majeure (e.g. floods, lightning, overvoltage, storms, fires, etc.)

In addition, normal wear or any other failure will not affect the basic operation of the product. Any external scratches, stains or natural mechanical wear does not represent a defect in the product.

8. Limitation of Liability

In addition to the product warranty described above, the state and local laws and regulations provide financial compensation for the product's power connection (including violation of implied terms and warranties). The company hereby declares that the terms and conditions of the product and the policy cannot and can only legally exclude all liability within a limited scope.

9. Datasheet

Model	SRP-UN-G3KW	SRP-UN-G3.6KW	SRP-UN-G4.2KW	SRP-UN-G5KW	SRP-UN-G6KW	SRP-UN-G8KW	SRP-UN-G10KW	SRP-UN-G12KW
Battery Input Data								
Battery Type	Lead-acid or Li-Ion							
Battery Voltage Range(V)	40-60							
Max. Charging Current(A)	70	90	98	120	135	190	220	250
Max. Discharging Current(A)	70	90	98	120	135	190	220	250
Charging Curve	3 Stages / Equalization							
External Temperature Sensor	yes							
Charging Strategy for Li-Ion Battery	Self-adaption to BMS							
PV String Input Data								
Max. DC Input Power(W)	3900	4680	5460	6500	7800	10400	13000	15600
PV Input Voltage(V)	370V (125V-500V)							
MPPT Range(V)	150-425V							
Full Load DC Voltage Range	200-425V							
Start-up Voltage(V)	125V							
PV Input Current(A)	13+13	13+13	13+13	13+13	13+13	20+20	26+26+26	26+26+26
No. of MPPT Trackers	2	2	2	2	2	2	3	3
No. of Strings Per MPPT Tracker	1+1	1+1	1+1	1+1	1+1	1+1	1+1+1	1+1+1
AC Input/Output Data								
Rated AC Output and UPS Power(W)	3000	3600	4200	5000	6000	8000	10000	12000
Max. AC Output Power(W)	3300	3900	4620	5500	6600	8800	11100	13200
Peak Power(off grid)	2 times of rated power, 10 S							
AC Input/Output Rated Current(A)	13.7/13.1	16.4/15.7	19.1/18.3	22.8/21.8	27.3/26.1	36.4/34.8	45.5/43.5	54.6/52.2
Max. AC Input/Output Current(A)	15/14.4	18/17.3	21/20.2	25/24	30/28.7	40/38.3	50/47.9	60/57.4
Max. Continuous AC Passthrough(A)	35	35	35	35	40	50	60	60
Power Factor	0.8 leading to 0.8 lagging							
Output Frequency and Voltage	50/60Hz; 220/230Vac							
Grid Type	Single Phase							
Total Harmonic Distortion (THD)	<3% (of nominal power)							
DC current injection	<0.5% In							
Efficiency								
Max. Efficiency	97.60%							
Euro Efficiency	96.50%							
MPPT Efficiency	>99%							
Protection								
PV Arc Fault Detection	Integrated							
PV Input Lightning Protection	Integrated							
Anti-islanding Protection	Integrated							

Datasheet


PV String Input Reverse Polarity Protection	Integrated			
Insulation Resistor Detection	Integrated			
Residual Current Monitoring Unit	Integrated			
Output Over Current Protection	Integrated			
Output Shorted Protection	Integrated			
Surge Protection	DC Type II / AC Type II			
Over Voltage Category	DC Type II / AC Type III			
Certifications and Standards				
Grid Regulation	IEC61727/62116,EN50549-1			
EMC/Safety Regulation	IEC/EN 61000-6-1/2/3/4,IEC/EN 62109-1,IEC/EN 62109-2			
General Data				
Operating Temperature Range(°C)	-40~60°C, >45°C Derating			
Cooling	Smart cooling			
Noise(dB)	<50 dB			
Communication with BMS	RS485; CAN			
Monitoring mode	Wi-Fi+APP			
Weight(kg)	24	29	31	31
Cabinet size(mm) (Excluding connectors and brackets)	340W×575H×255D	413W×630H×257.5D	413W×630H×257.5D	413W×630H×257.5D
Protection Degree	IP65			
Installation Style	Wall-mounted			
Warranty	5 Years (10 Years Optional)			

Appendix I


10.Appendix I

Definition of RJ45 Port Pin for BMS 485/CAN.

No.	BMS 485/CAN Pin
1	485_B
2	485_A
3	GND_485
4	CAN-H
5	CAN-L
6	GND_485
7	485_A
8	485_B




BMS 485/CAN Port




Definition of RJ45 Port Pin for RS 485.

This port is used to communicate with energy meter.

No.	RS 485 Pin
1	--
2	--
3	--
4	485_B
5	485_A
6	--
7	--
8	--




RS 485 Port



RS485

Pin	Pin Name	Pin Type	Description	Typ.
1	VCC	Power	Power	DC 4.8V-5.2V
2	D-	Digital Differential	RS-485 B	-
3	D+	Digital Differential	RS-485 A	-
4	GND	GND	GND	DC 0V



WIFI/RS485

This RS485 port is used to connect the wifi datalogger

Appendix II

11. Appendix II

1. Split Core Current Transformer (CT) dimension: (mm)
2. Secondary output cable length is 4m.

